

IBIZA

With clean-lined modern style, our Ibiza outdoor dining set is crafted of aluminium frames with a durable powder coat finish. All pieces in the Ibiza collection have been topped with FSC certified Teak tops giving that touch of elegance without the price tag!

Ask our staff about delivery options.



FRAME/TIMBER
WICKER



WOOD/TEAK



IDEAL FOR
COASTAL
LOCATIONS



RUST FREE



220 DINING TABLE
W220 x D100 x H74cm



150 DINING TABLE
W150 x D75 x H74cm



195 DINING BENCH
W195 x D40 x H44cm



120 DINING BENCH
W120 x D35 x H44cm

 **TARGET**

   [targetfurniture.co.nz](https://www.targetfurniture.co.nz)

Nationwide Delivery | 0800 TARGET (0800 827 438)

IBIZA CARE INSTRUCTIONS

Our outdoor furniture is made with the highest quality outdoor materials however there is some maintenance required to keep the furniture looking fresh so that you can enjoy it for years to come. Here are a few things you may want to know.

BEST SUITED FOR:

Sun soaked decks and patios.

BEFORE FIRST USE:

To prolong the life of the Teak top, we highly recommend rubbing Teak oil. Available from Target or any hardware store.

WINTERISING YOUR OUTDOOR FURNITURE:

If space is available, it's ideal to move your furniture into a sheltered location such as a your garage. If this isn't practical, consolidate pieces into the smallest possible space, remove cushions to store indoors and cover the setting with a high quality outdoor cover. The best outdoor covers have air vents that let air circulate, preventing mould and mildew from growing.

AFTER EACH USE:

To keep your outdoor settings looking fresh, it is recommended to bring cushions inside and cover the tables.

TO CLEAN FURNITURE:

1. Remove all cushions.
2. Use a garden hose to completely wash down furniture.
3. Mix together a cleaning solution use a mild soap and lukewarm water.
4. Use a soft bristle brush to gently clean the furniture.
5. Wash it down again using the hose until all the soap is gone.
6. Air dry outside.
7. Once dry, rub in an oil specifically for Teak timber.

NOW AND THEN:

Regular oiling will protect the timber from the harsh outdoor environment. Every 6 months, it is recommended to re-tighten the screws, especially on dining chairs and benches.

MIX & MATCH YOUR IBIZA SETTING.



BAILEY DINING CHAIR
W54 x D52 x H83cm



TIVOLI DINING CHAIR
W62 x D63 x H79cm

COMPLIMENT YOUR IBIZA SETTING.




TAHITI CANTILEVER UMBRELLA – BLACK
W300 x W300 x H250cm
Base sold separately.

WARNER THROW - SILVER GREY
125 x 150cm

PROTECT YOUR IBIZA SETTING



PREMIUM FURNITURE COVER
Available in Small/Large Rectangle, Oval, Circle or Lounge sizing.



HOKITIKA FLOOR RUG EASTLAND - BRACKEN
160 x 230cm / 200 x 290cm
Huge range available, see online or in store.