

# MIAMI

Made from durable Karri Gum, the Miami Collection has a timeless classic look about it that has long been a kiwi favourite. Choose from multiple dining configurations all designed to maximise your outdoors this summer.

Ask our staff about delivery options.



FRAME/TIMBER  
WICKER



COVER  
INCLUDED\*



WOOD



IDEAL FOR  
ENTERTAINING



240 DINING TABLE with Granite Insert \*  
W240 x D120 x H75cm



ROUND DINING TABLE \*  
DIA150 x H73cm



LAZY SUSAN  
DIA60cm



BENCH SEAT  
W155 x D35 x H45cm  
Cushion included.



180 DINING TABLE \*  
W180 x D100 x H75cm



DINING CHAIR  
W60 x D66 x H95cm  
SH50cm  
Cushion sold separately

**TARGET**

[targetfurniture.co.nz](https://www.targetfurniture.co.nz)

Nationwide Delivery | 0800 TARGET (0800 827 438)

## MIAMI CARE INSTRUCTIONS

Our outdoor furniture is made with the highest quality outdoor materials however there is some maintenance required to keep the furniture looking fresh so that you can enjoy it for years to come. Here are a few things you may want to know.

### BEST SUITED FOR:

Outdoor areas protected from long exposure to sun. Using umbrellas or sun-shades is an easy way to provide shade for yourself and the furniture.

### BEFORE FIRST USE:

To prolong the life of wooden outdoor furniture, it is recommended to rub in an outdoor furniture oil. Available from Target or any hardware store.

### AFTER EACH USE:

To keep your outdoor settings looking fresh, it is recommended to bring cushions inside and use an outdoor cover for the dining settings.

### WINTERISING YOUR OUTDOOR FURNITURE:

If space is available, it's ideal to move your furniture into a sheltered location such as a your garage. If this isn't practical, consolidate pieces into the smallest possible space, remove cushions to store indoors and cover the setting with a high quality outdoor cover. The best outdoor covers have air vents that let air circulate, preventing mould and mildew from growing.

### TO CLEAN FURNITURE:

1. Remove all cushions.
2. Use a garden hose to completely wash down furniture.
3. Mix together a cleaning solution use a mild soap and lukewarm water.
4. Use a soft bristle brush to gently clean the furniture.
5. Wash it down again using the hose until all the soap is gone.
6. Air dry outside.
7. Once dry, rub in an oil specifically for outdoor furniture.

### NOW AND THEN:

Regular oiling will protect the timber from the harsh outdoor environment. Every 6 months, it is recommended to re-tighten the screws, especially on dining chairs and benches.

## COMPLIMENT YOUR MIAMI SETTING



### KAPRICE ROUND UMBRELLA

H270cm

Base sold separately.



### IN & OUTDOOR CUSHION

Branch Stripe Spruce Green / Oneroa Multi  
50 x 50cm / 35 x 50cm

Huge range available, see online or in store.



### ALBERS THROW – MOSS

125 x 150cm

## PROTECT YOUR MIAMI SETTING



### OUTDOOR TIMBER CARE KIT



### PREMIUM FURNITURE COVER

Available in Small/Large Rectangle, Oval, Circle or Lounge sizing.